

Countertop Reverse Osmosis System

RO4000 - 4 Stage Drinking Water Filter System

PLEASE READ CAREFULLY BEFORE ATTEMPTING MAINTENANCE

System Assembly Diagram 1



Labelled Components

- 1 Carbon Pre-Filter Made in USA
- 2 RO Membrane Made in USA
- 3 Carbon Post Filter Made in USA
- 4 Alkaliser Filter Made in USA
- A Diverter
- B 1/4" white tube FOOD GRADE
- C Pressure Gauge
- D 1/4" black tube FOOD GRADE
- E 1/4" blue tube FOOD GRADE

Step by Step Maintenance

Before attempting maintenance please ensure you have switched off the feed water to your system.

- 1. Remove the cover by compressing the clips at each end of the unit.
- 2. Taking note of the direction indicated on the filter label, unscrew the Carbon Pre-Filter and dispose.
- 3. Unscrew the Carbon Post-Filter and re-install it in the position of the Carbon Pre-Filter. The Carbon Post-Filter has only been used as a polishing filter, hence it can be re-used as the Carbon Pre-Filter.
- 4. For instructions on how to replace the RO membrane* please see Page 2.

- 5. Install the new Carbon Post-Filter by inserting the new filter into the existing head assembly.
- 6. To replace the Alkaliser Filter, remove the stem elbow (with blue tube inserted) from both the inlet and outlet of the filter cartridge - pushing on the filter's collet whilst pulling the stem elbow. To install the new filter; if necessary remove any dust plugs and re-attach the stem elbows with the blue tube inserted.
- 7. Flush the system before use; with the blue tube feeding to a drain, run water through the system for a few minutes. Dis-colouration and aeration may occur this is normal and occurs when the non-toxic carbon fines and oxygen are flushed from the new cartridges.

* Depending on water quality and usage, your RO Membrane should last 3-6 years. Your pure water quality can be tested with a conductivity meter measuring total dissolved solids (TDS) from the pure water outlet - this will indicate the rejection of contaminants ratio. Purchase a TDS Reader or alternatively a complimentary service is available at either of our showrooms listed below.



North Shore Showroom 425 Miller Street. Cammeray NSW 2062 Inner West Showroom 342-350 Parramatta Road, Stanmore NSW 2048